

3D Convertible Car Model

Assembly Instructions

NB to ensure the model stays in one piece after assembly it is advisable to use a tiny drop of superglue to lock pieces together.

Each piece of the model is numbered for easy assembly.

The letters are the vehicle parts and the numbers are the slots on the parts.

To prevent parts from breaking, remove carefully.

Before you use superglue to permanently glue the convertible together, use a small ball of prestik to hold the pieces in place to ensure they all fit, allowing you to dismantle the convertible if required.

1. Take **A** (the floorboard) and attach it to slots **1** and **2** found on **B1** & **B2** (the inner car body).
2. Attach **C** (the seats) to slots **3** and **4** found on **B1** & **B2** - first the seating **3**, then the back of the seat **4**.
3. Place **D** (the boot) into slot **5** on **B1** & **B2**.
4. Place **E** (vehicle tailgate) into slot **6** on **B1** & **B2**.
5. Assemble the bonnet **F1**, **F2** & **F3**.
 - a. Place **F1** (lower bonnet piece) into slot **7** on **B1** & **B2**.
 - b. Attach **F3** to **F2** in slot **9**.
 - c. Attach this to **F1** in slot **8**.
6. Attach **G** (steering wheel) into slot **10** on **B1**.
7. Assemble convertible frame & cover **H1**, **H2** & **H3**.
 - a. Attach **H1** to slot **11** on **A** and slot **20** on **D**.
 - b. Place **H2** & **H3** into slot **20** on **D**.
8. Take **I1** & **I2** (outer car body) and attach to slots **14** & **15**.
9. Take **J** (windscreen) and attach to slot **15**.
10. Assemble front bumper **K1** & **K2**.
 - a. Place **3** by **K2** into slots on part **K1**.
 - b. Attach complete bumper assembly into slot **17** on **I1** & **I2** - making sure **K2** shows upwards.
11. Assemble rear bumper part **L**.
 - a. Place **L** into slots **18** & **19** on parts **B** & **I**.
12. Assemble side mirrors **N1** & **N2** - 2 sets.
 - a. Attach parts **N1** & **N2** together.
 - b. Slide this into slot **23** on **I1** & **I2** on each side of the vehicle.
13. Take **M1** & **M2** (axles) and attach to slots **21** & **22** found on **B1** & **B2**.
14. Finally assemble the wheels **P1**, **P2** & **P3**.
 - a. Slide inner wheel **P1** with detail facing towards the vehicle onto axle **21** & **22**.
 - b. Slide outer wheel **P3** with detail facing away from the vehicle onto axle **21** & **22**.
 - c. Attach **P3** to slot **25** (on the axles).



